

Progressive® with S4™ GRATER SURFACE sharp straight simple smart™

Smart Slice

At Progressive our goal is to make your busy life easier with innovative products for your kitchen. This Smart Slice slices, julienne sticks and grates food with ease.

Features / Benefits


- No Removable Blade
- 4 Thickness Settings for Slices and Julienne
- Extra Sharp Grater
- Hand Guard
- Bowl Grooves
- Dishwasher Safe

- Sharp**
 - Angled Blade Cuts with Minimal Effort
 - Julienne Blades Make Sticks Easily
- Straight**
 - V-Blade Grating Surface for Superior Performance and Control
 - Straight Tracking Guide for Easy Use and Keeps All Parts Together
- Simple**
 - All in One, No Removable Blades, Compact for Storage
 - Two Adjustable Knobs Make it Easy to Select Slice Thickness and Engage Julienne Blades
- Smart**
 - Ergonomic Hand Guard for Greater Control
 - Self-Feeding Holds Skinny Foods for Slicing



ProTip

To remove food stains, place Smart Slice blade in locked position simply apply a small amount of olive oil to a paper or cloth towel and carefully rub stain away.



Cleaning

- Wash first before using the Smart Slice.
- Slide **Food Holder** off the track.
- Move **Thickness Adjustment Knob** to locked position.
- Fold legs into base.
- If Grater was used, flip ramp into open position to allow soap and water to reach the grater surface.
- Place all pieces into dishwasher.




⚠ Caution!

- Use care when operating and washing this item to avoid injury.
- Turn **Thickness Adjustable Knob** to lock position when not in use, or for storage.
- Always use **Hand Guard** when in use.
- Do not place thumb or fingers in **Green Self-Feeding Tube**.




To Use the Slicer

1. Unfold **Folding Legs** from underside of slicer.
2. To attach **Food Holder** to the slicer body, insert green guide into the track located at the front of the slicer foot.
3. For slices turn **Thickness Adjustment Knob** on side to desired slice thickness.
4. For Julienne Sticks, turn the **Julienne Adjustment Knob** on the side to raise blades.
5. Place food into **Food Holder** then insert **Hand Guard** into **Food Holder**.
6. Begin slicing with fingers in hand grip. **ALWAYS USE HAND GUARD WHEN IN USE. WARNING! DO NOT PLACE THUMB OR FINGERS IN THE GREEN FEEDING TUBE.**
7. To slice small food such as carrots, insert **Hand Guard** into **Food Holder** and insert food into **Green Self-Feeding Tube** on top of hand guard. Food will automatically drop down after each pass, no pressure needed on food.








To Use the Grater

1. Slide **Food Holder** 1/2 way down the track and flip up.
2. Lift up tab at front end of slicer to reveal grater.
3. Fold lower half of ramp over **Angled Slicer Blade** and snap into place.
4. Flip **Food Holder** down, insert food and hand guard. Begin grating.



Thickness Guide



-  Lock - For storage and cleaning
-  Setting 1 - Approximately 1/16" (.157 cm)
-  Setting 2 - Approximately 1/8" (.318 cm)
-  Setting 3 - Approximately 3/16" (.475 cm)
-  Setting 4 - Approximately 1/4" (.635 cm)

Tip

Use firm tomatoes when trying to achieve thin slices.